



## 130 Fanlight Stay

Stay Knuckle

### Left hung or top hung positioning

(Stay is fitted to the right side or bottom of the window)

**NOTE:** When printing, do NOT print to "Fit". Print at "100%" or "Actual size". You will lose some of the template at either end, but it will work as long as you have the positioning for one of the knuckle drill holes.

Window

FOLD ALONG LINE

Peg

Frame / Sill

Peg